

IRON-ON INSTRUCTIONS



1

THE **STEAM** SETTING MUST BE **OFF** BEFORE YOU START TO APPLY THE PATCHES.



2

PRE-HEAT YOUR IRON TO THE MAX OR SET YOUR IRON ON COTTON/LINEN.



3

PLACE THE PATCH ON THE DESIRED SPOT FRONT SIDE UP, SHINY SIDE DOWN.

CLEAN AND DRY YOUR GARMENT BEFORE APPLYING THE PATCHES.



4

IRON OVER THE PATCH WITH REAL PRESSURE FOR **60** SECONDS.

DO NOT IRON LONGER THAN 120 SECONDS.

PAY SPECIAL ATTENTION TO THE CORNERS OF THE PATCH.



5

IRON AGAIN ON THE REVERSE SIDE FOR **30** SECONDS.

DO NOT IRON LONGER THAN 60 SECONDS.

6

ALLOW GLUE TO **DRY FOR 24 HOURS.**

DON'T WEAR OR WASH YOUR GARMENT DURING THIS TIME.



7

IN CASE THE PATCH STARTS TO PEEL OFF AFTER SOME TIME, JUST RE-IRON THE PATCH AGAIN. ONE PATCH CAN BE RE-IRONED UP TO **3** TIMES, EVEN AFTER WASHING.



YOU CAN ALSO **APPLY PATCHES FROM THE INSIDE** OF YOUR GARMENT.

THIS WAY, THE BACK SIDE (SHINY SIDE) OF THE PATCH SHOWS THROUGH THE HOLE.

AFTER COUPLE WASHES SHINY GLUE WILL DISAPPEAR AND IT WILL LOOK LIKE NORMAL FABRIC.

BUT BE CAREFUL DON'T LET PATCHES STICK TO THE OTHER SIDE OF THE JEANS THRU THE HOLE.

RECOMMENDED PUTTING BAKING PAPER TO PREVENT STICKING TO THE OTHER SIDE OF GARMENT.



WWW.ZEFFKA.COM



[@ZEFFKA_OFFICIAL](https://www.instagram.com/ZEFFKA_OFFICIAL)



WWW.YOUTUBE.COM/ZEFFKA

composition: 100% cotton, polyamide adhesive



Made in EU